
Estimating G/T from Sun Noise

April 14, 2023



The power received by pointing an antenna at the sun P_{sun} and a quiet area of sky P_{quiet} is commonly used to estimate receiver G/T [2]. The power in Watts delivered to the receiver Rx for each measurement is:

$$P_{sun} = (kT_{sun}B + kTB)G$$

$$P_{quiet} = kTBG$$
(1)

where G is the antenna power gain referenced to an isotropic antenna and T is the system noise temperature; the sum of all noise temperature sources such as feedline losses, LNA, ground spillover, and sky noise, and T_{sun} is the noise temperature of the sun at the time of the measurement. The Y factor is the ratio of the two measurements:

$$Y = \frac{P_{sun}}{P_{quiet}}$$

$$= \frac{(T_{sun} + T)kBG}{TkBG}$$

$$= \frac{T_{sun} + T}{T}$$
(2)

Solving for T we have:

$$T = \frac{T_{sun}}{Y - 1} \tag{3}$$

The power received from the sun can also be expressed in terms of the measured flux density (available for a given day from government observatories):

$$P_{sun} = \frac{FA_e}{2} \tag{4}$$

where F is the power flux density of the noise from the sun in $W/m^2/Hz$, and A_e is the effective area of the antenna. The power from the sun has random polarization, therefore only half of the power is delivered to the receiver as the relationship to effective area A_e assumes matched polarization [1, p 778]. The effective area of an antenna is given by [3, Eq 2.3]:

$$A_e = A_e^{iso}G$$

$$A_e = \frac{\lambda^2}{4\pi}G$$
(5)

where A_e^{iso} is the effective area of an isotropic antenna and G is the ratio of the antenna power gain to an isotropic antenna (note linear power gain, not dBi). Substituting (5) into (4):

$$P_{sun} = \frac{F\lambda^2 G}{8\pi} \tag{6}$$

Using the relationship P=kTB, and noting B=1 as F is defined in a 1 Hz bandwidth:

$$T_{sun} = \frac{P_{sun}}{k} = \frac{F\lambda^2 G}{8\pi k} \tag{7}$$

Substituting (7) into (3):

$$T = \frac{F\lambda^2 G}{8\pi k(Y - 1)}\tag{8}$$

Re-arranging we obtain the commonly used expression for estimating G/T from P_{sun} and P_{quiet} :

$$G/T = \frac{8\pi k (P_{sun}/P_{quiet} - 1)}{F\lambda^2}$$
(9)

Note that P_{sun} and P_{quiet} are linear power (e.g. W or mW, not dBW or dBm), and G/T is a linear power ratio with units K^{-1} , commonly converted to dB and expressed as dB/K.

References

- [1] John D Kraus. Antennas. McGraw-Hill, 1988.
- [2] Richard Flagg, AH6NM. Determination of G/T, 2006. http://www.setileague.org/articles/g-t.htm.
- [3] Robert J. Zavrel. Antenna physics: An introduction. ARRL, 2016.